Carplay Function Introduction

Main Interface



- 1. Supports iphones with iOS13 and later versions.
- 2. This product is wired CarPlay, please connect the phone through the marked USB [~] port before use.
- 3. Before use, please check whether there is CarPlay car option in [Settings → General], if not, please check [CarPlay] option in [Access Restrictions].
- 4. You need to enable Siri on your phone to use CarPlay.
- 5. When the phone prompts [Allow "GEELY" to use CarPlay while the phone is locked?] please select [Allow].
- 6. After CarPlay is connected, it will automatically enter the CarPlay interface. After manually switching to the background, you can re-enter CarPlay through the CarPlay icon on the main interface.
- 7. Bluetooth is disabled after CarPlay connection, you can make calls through CarPlay, and press the phone button to enter the CarPlay phone interface.

Precautions when using

- 1. If there is any problem in use, please try again after plugging.
- 2. To ensure a stable CarPlay connection, please use an Apple MFi-certified data cable.
- 3. After disconnecting CarPlay, the time interval between reconnections should be greater than 5s.
- 4. Some communication apps do not support message text viewing functions for the time being, such as Messages, WhatsApp, etc.
- 5. The navigation map in CarPlay does not support the dual-finger zoom function for the time being. You can zoom and view the map through the [+], [-] function button

on the map.

- The navigation map in CarPlay does not support single-finger drag function for the time being. You can view the map by moving [^], [^], [^], [^], on the map.
- 7. It is recommended to use CarPlay after upgrading the phone to the latest iOS version.